

1. Strip the wire.

2. Attach the sleeve and inner conductor.

3. Crimp the inner conductor.

4. Snap the inner conductor into the contact.

5. Tap the shield on.

6. Slide the sleeve forwards and crimp.

